


1. All external cables must run through trunking or bellows, and no cable is allowed to be exposed.
2. Arrange and install cables in strict accordance with the circuit diagram. All external cables must be marked according to the cable number, and the line marks at both ends shall be clear and firm.
3. The wiring cable must remain slack.
4. Hydraulic oil filling 46 # anti-wear hydraulic oil.

MTK	MTK-1560			
Circuit layout				